1.open folder

1，2. If the PC's system is WINDOWS 64 bit，double click the

of 9.STM32 to install the program of USB-COM; If the PC's system is WINDOWS 32 bit，double click the

of 9.STM32 to install the program of USB-COM

3. Factory   Default


4.Bluetooth   Mode


5,Bluetooth Baud   Rate

6,Bluetooth   Setting   Mark


7,Enter   Setting

8,Open   SPP   Channel

9, Disconnect previous connection

|||| ||| |||| | ||| ||||| ||| ||| |||||| ||| ||| |

10 Scan the receiver's MAC code(The code is sticked on the receiver's outer case)
11. Auto reconnection

||| ||| || |||| ||| ||| ||||| ||| ||||| ||| |||| || |||

12. Storage Bluetooth SPP setting

||| ||| | |||| ||||| ||| |||| ||||| ||| ||| |||| | |

13. Finish Bluetooth SPP setting

|||| ||| ||| |||| ||| || ||||| ||| ||| || |||| ||||

14. IOS Transmission OFF

||| ||| ||| ||| || ||| |||| ||| ||| ||| ||| | ||| |||

15.USB-COM

||| |||| ||| ||| |||| ||| ||| ||| |||| ||| || ||||| |||